


## Front

Vorderseite / Face avant / Parte anteriore /  
Parte delantera / Вид спереди / Parte frontal



2D

3D ▲



No driver installed

Kein Treiber installiert

Aucun pilote installé

Nessun driver installato

No se ha instalado el controlador

Драйвер не установлен

Nenhum driver instalado

## USB IR Emitter

USB-IR-Sender / Émetteur IR USB / Emittitore  
IR USB / Transmisor de infrarrojos USB /  
USB ИК эмиттер / Emissor IV via USB

Designed to be used with 3D Vision wireless  
glasses with products without a built-in  
IR emitter.

Zur Verwendung mit 3D Vision Wireless-  
Brillen für Produkte ohne integrierten  
IR-Sender.

Conçu pour une utilisation avec les lunettes  
sans fil 3D Vision et les produits dépourvus  
d'un émetteur IR intégré.

Progettato per l'utilizzo con gli occhiali  
wireless 3D Vision per prodotti senza  
emettitore IR integrato.

Diseñado para usar con gafas inalámbricas  
3D Vision en productos sin transmisor de  
infrarrojos integrado.

Предназначен для использования с  
беспроводными очками 3D Vision  
для устройств без встроенного  
ИК-передатчика.

Desenvolvido para ser usado com óculos  
3D sem fio para produtos sem um emissor  
infra-vermelho integrado.



176-0139-000

## Back

Rückseite / Dos / Retro / Parte posterior /

Вид сзади / Parte traseira

